

Installation Guidelines

Accessories

CGR119 Rubber Corner Guard

Data Sheet: (sheet 1 of 1) 28/02/08

Please read the following prior to installation of Gradus CGR119 Rubber Corner Guard

1) Cut the corner guard to the desired length. Select a No12 screw suitable for the substrate. Drill 7mm diameter holes in the corner guard.

Note When drilling the corner guard the holes on each side should be staggered i.e. one side start to drill 15mm from the top of the profile. On the other side begin to drill 25mm from the top of the profile. Space the remaining holes over the entire length of the corner guard.

2) Using the corner guard as a template transfer the hole locations to the wall.
Drill the wall using the drill size recommended by the fixing manufacturer.

3) Attach the corner guard to the wall with flat washers and fasteners.

Please call Technical Services on 01625 428922 for any further assistance