

Installation Guidelines

Accessories

D-Fender Rubber Wall Guard

Data Sheet: (sheet 1 of 1) 06/03/09

Please read all the instructions before installing the wall guard

1. Cut the wall guard to the desired length and select a Nr 10 fixing appropriate to the substrate being fixed to.
2. Drill a 30mmØ access hole through the front of the D-Fender and then drill 8mmØ holes in the back of the D-Fender
3. Using the D-Fender as a template, mark the location of the mounting holes on the steel plate. Use 8mmØ steel drill.
4. Use the D-Fender as a template to mark the location of mounting holes to the wall. Drill holes in the substrate using the appropriate drill size for the fixings being used.
5. Slide the steel plate into the D-Fender and attaché the wall guard to the wall with the appropriate fixings for the substrate.

If any further information is required, please do not hesitate to contact Gradus Technical Services on (+44)1625 428922 or fax on (+44)1625 425226