

Specification Sheet No

PFSA
01

Description

POLYFLOR RECYCLED
RUBBER WALL PROTECTOR -
WPSXT195E

Date

APRIL
2022

ARCHITECTURAL SPECIFICATION / BOQ

SPECIFICATION:

WPSXT195E

Supply and install heavy duty Polyflor SA recycled rubber **WPSXT195E** Wall Protector 195mm X 32mm X 2900mm coated with an antibacterial water based acrylic coating, for protection against severe damage caused by wheeled traffic, suitable for exterior and interior use, ideal for use in warehousing, back of house, loading bays, service corridors, parking areas etc

INSTALLATION:

WPSXT195E

1. Cut the Wall Protector to the correct length using a sharp bladed tool.
2. Mark the Wall Protector for holes at 50mm from each end, along the upper and lower channels. Also mark holes evenly along the length at spacings of approximately 300mm but no greater than 400mm.
3. Drill 4mm holes through the Wall Protector at each one of the marked positions.
4. Using a level, establish where the top of the Wall Protector would sit against the wall.
5. Position the Wall Protector against the wall using a straight edge support to prevent sagging as it is used as a template for marking the position of the fixing point holes in the wall.
6. Remove the Wall Protector and drill 6.5/ 7mm holes in the wall ready for appropriate fixings.
7. Recommended fixings are masonry torx frame fixing screws 7.5 x 102mm. A loose fit of all the fixings to a depth of approximately half their screw depth is recommended to check for correct alignment before fully tightening.

SPECIALIST FLOORING & WALL PROTECTION PARTNER

Tel: 011 609 3500 | Email: marketing@polyflor.co.za | www.polyflor.co.za
Poly Sales House, 8B Buwbes Road North, Sebenza, 1609, South Africa. PO Box 3967, Edenvale, 1610, South Africa

Poly Sales Africa (Pty) Ltd. trading as Polyflor South Africa. Company Registration 2004/012256/07
Directors: DL Coleman, P du Plessis, T Coleman, A Mc Lardy

MAINTENANCE:

Preventative Maintenance Programme

A regular scheduled maintenance programme should be employed to prevent the build-up of dirt and grease, which will detract from the overall appearance of the product.

Upon completion of installation, all rubber surfaces should be checked and thoroughly cleaned to remove any adhesive or spot marks. (Remove excess adhesive with methods and materials recommended by the adhesive manufacturer).

Twice Weekly

To avoid heavy build-up of soil, the rubber profile should be periodically cleaned. It is recommended that this operation be carried out using soap less neutral detergent in warm water and rinsing with clean water using a soft cloth.

Stubborn marks may be removed by means of a citrus cleaner, on completion rinse thoroughly with clean water.

After cleaning, dry thoroughly with a lint free cloth.

Regular cleaning in the prescribed manner will maintain the appearance of the product.

