

SPECIFICATION SHEET NO	DESCRIPTION	DATE
IG207	GRADUS BHPA125 BED HEAD PROTECTOR	FEB 2026

INSTALLATION GUIDE

Important: Prior to installation, ensure that the wall/substrate can support the products/fixings being used.

1. Use a 6mm drill bit to make two holes along the v-notch in the aluminium retainer at 10mm from both ends of the retainer for the end-cap bolts. Fit the endcaps, with reveals fitted, onto the retainer. Fit the washer over the bolt, feed the bolt through the retainer and secure using the locking nut.
2. Use a 6mm drill bit to make 2 holes in the centre of the aluminium retainer at 100mm from both ends of the retainer. These holes can be used for stand-off brackets.
3. Use the 2 holes in the retainer as a template for marking the holes needed to mount the protector, checking with a laser level that the lower holes of each pair of Bed Head Protectors are on the same level.
4. For all drilled holes, ensure that appropriate plugs and/or fasteners are used and that there is sufficient length of threaded fastening available for the fixing screws (not supplied).
5. Mount the retainer/end cap modules to the wall with the BHPA125/BRKT and ensure they are tight and secure. Clip the inner bumper onto the retainer slightly short of the end caps.
6. Check that the reveals are sitting flush with the endcaps before placing the PVC-u cover on the retainer. Firmly push the PVC-u cover down against the lower reveal while hooking one side of the PVC-u cover on one side of the retainer. Snap the PVC-u cover into place by pushing firmly but slowly on the PVC-u cover.

Fitters Tips:

- For custom length bed head protectors which need to be cut on site, the PVC-u cover may try and compress under the pressure of the saw blade during the cutting process. This can be reduced by cutting slowly and cutting from the back of the cover.
- When fitting several bed head protectors, it can save time to set-up a template.

MAINTENANCE:

A regular scheduled maintenance programme should be employed to prevent the build-up of dirt and grease, which will detract from the overall appearance of the product and can lead to the spread of germs and bacteria.

Apply a neutral cleaner to a micro fibre cloth and wipe the surface of the profile. When cleaning handrails, particular attention should be paid to the underside of the handrail as this is where dirt and grease can build up.

The cleaned surface should then be 'rinse wiped' using clean water and then thoroughly dried using a soft cloth. This ensures all cleaning residue is removed.

Abrasive cleaners, solvents, or cleaning pads (e.g., Thinners, Turpentine, Handy Andy) should NOT be used as they will damage the profile surface.

BUILDING ENDURING VALUE

Tel: 011 609 3500 | Email: marketing@polysales.com | www.polysales.com
Poly Sales House, 8B Buwbes Road North, Sebenza, 1609, South Africa. PO Box 3967, Edenvale, 1610, South Africa

Poly Sales Africa (Pty) Ltd. trading as Polysales Company Registration 2004/012256/07
Directors: DL Coleman, P du Plessis, T Coleman